

Sutanu Bera
Roll - CSE/22107/0961
Algorithm II Lab (CSC711)
Lab - 05

PROGRAM FILES LINK:

Polygon Monotonicity & Triangulation (Ear Clipping Method): [CLICK](#)

ALGORITHM:

1. Checking Polygon Monotonicity

A polygon is monotone with respect to an axis (say x or y) if every line perpendicular to that axis intersects the polygon boundary at most two times. This means the polygon can be split into two monotone chains.

Steps to check monotonicity (for x or y axis):

1. **Input:** A polygon represented as a sequence of vertices in order.
2. Choose an axis (x or y).
3. Traverse the polygon edges in order and compute the **direction of movement** along that axis:
 - **+1** → increasing (right/up)
 - **-1** → decreasing (left/down)
 - **0** → flat (ignore).
4. Compress consecutive same directions into one (remove repeats like +1,+1).
5. Count the number of **direction changes**.
6. If the number of changes = **2**, then polygon is **monotone** with respect to that axis.
7. Otherwise, it is **non-monotone**.

2. Triangulation (Ear Clipping Method)


A triangulation splits the polygon into non-overlapping triangles using diagonals.

Ear Clipping Steps:


1. **Input:** A simple polygon (must be monotone for correctness).
2. Ensure polygon vertices are ordered **counter-clockwise (CCW)**. If clockwise, reverse.
3. Store vertices in a list.
4. While polygon has more than 3 vertices:
 - Pick a vertex v_i and its neighbors (v_{i-1} , v_i , v_{i+1}).
 - Check if it forms a **convex angle** (CCW orientation).
 - Ensure no other vertex of the polygon lies **inside** this triangle.
 - If both conditions true \rightarrow it's an **ear**.
 - Clip the ear:
 - Add diagonal (v_{i-1} , v_{i+1}) to triangulation list.
 - Remove vertex v_i from polygon.
5. Continue until only one triangle remains.
6. Output the diagonals (triangulation).

INPUT AND OUTPUTS:


Test 2 – y-monotone
Monotone Type: y-monotone



Test 3 – non-monotone
Monotone Type: non-monotone



Test 1 – x-monotone
Monotone Type: x-monotone



```
Test 1 ? x-monotone | x-monotone=true y-monotone=false  
Triangulation produced 5 diagonals (5 expected).  
Test 2 ? y-monotone | x-monotone=false y-monotone=true  
Triangulation produced 5 diagonals (5 expected).  
Test 3 ? non-monotone | x-monotone=false y-monotone=false  
Polygon is non-monotone; triangulation skipped.
```